



New Era Tech Quick Start Guide





The Digiwrist Kit allows you to
instantly call plays
Securely, Wirelessly, and OFF GRID.

YOUR SYSTEM ARRIVES:

- Pre Paired
- Locked to your team
- Ready to use out of the box

NO SETUP REQUIRED

HOW TO USE

Step 1 - Power On

1. Power on tablet
2. Power on receivers
3. Power on DWT Booster (if included)

Step 2 - Launch App

1. Tap Digiwrist icon
2. Log in if required (WiFi needed for login if logged out)

Step 3 - Connect Transmitter

1. Plug transmitter + cable into tablet
2. Tap "OK" when prompted

Step 4 - Load Plays

1. Select Offense or Defense.
2. Tap  (WiFi required) OR Enter plays manually and tap save

Step 5 - Call Play

1. Select play.
2. Tap SEND.

Receivers vibrate: 2 times standard; 3 times with Booster.

No WiFi, Cellular, OR Bluetooth required during game play.



DIGIWRIST POWER GUIDE



Receivers

15+ hours
battery life

Full Charge
in 45min

Charge after
each use

* Powers off after
2hrs automatically



Tablet

12+ hours play
time

Charge after
each use

Turn off after
use



DWT Booster

24+ hours
battery life

Full Charge
in 20 hours

Turn off after
use



Maximize Performance. Charge Regularly.

DIGIWRIST WATER RESISTANCE



Receivers



Tablet



Transmitter/ Booster



Cloth OK to wash... in fact, we recommend it!



Q/A

IF Logged out

Connect tablet to wifi(shool wifi might prohibit) or phone hotspot

1. Login
2. If it still does not work restart Tablet and repeat
 - A. Still nothing? Call us you might need a Password reset.

Pairing New Receivers

1. **DO NOT ATTEMPT BEFORE CALLING US.** It is very simple once you know how.

Damaged During Use

1. Please send us an email to info@digiwristtech.com including pictures and organization name so that we can process your replacement

Need New Cloth

1. If you are under our lease to own option you will get a new set of cloth prior to season 2. If you need additional cloth mid-season please email info@digiwristtech.com with your request.

